


TAP100






HARDWARE

TOP VIEW



BOTTOM VIEW



RJ45 LED MEANING





FEATURES

WIRFLES	

Wireless mode	802.11b/g/n (Wi-Fi 4)	
Wi-Fi security	WPA2-Enterprise - PEAP, WPA2-PSK, WPA-EAP, WPA-PSK, WPA3-SAE, WPA3-EAP, OWE; AES-CCMP, TKIP, Auto-cipher modes, client separation, EAP-TLS with PKCS#12 certificates, disable auto-reconnect	
SSID/ESSID	SSID stealth mode and access control based on MAC address	
Wi-Fi users	Up to 100 simultaneous connections	
Wireless Connectivity Features	Wireless mesh (802.11s), fast roaming (802.11r), BSS transition management (802.11v), radio resource measurement (802.11k)	
Wireless MAC filter	Whitelist, blacklist	
Wireless QR code generator	Once scanned, a user will automatically enter your network without needing to input login information	
ETHERNET		
Ethernet	1 x RJ45 port 10/100 Mbps, compliance with IEEE 802.3, IEEE 802.3u, 802.3az standards, supports auto MDI/MDIX crossover	
NETWORK		
Network protocols	TCP, UDP, IPv4, IPv6, ICMP, HTTP, HTTPS, SSL v3, TLS, ARP, SSH	
DNS over HTTPS	DNS over HTTPS proxy enables secure DNS resolution by routing DNS queries over HTTPS	
Hotspot	Captive portal (hotspot), internal/external Radius server, Radius MAC authentication, SMS authorisation, SSO authentication, internal/external landing page, walled garden, user scripts, URL parameters, user groups, individual user or group limitations, user management, 9 default customisable themes and optionality to upload and download customised hotspot themes	
SECURITY		
802.1x	Port-based network access control client	
Authentication	SSH key based, HTTPS, CLI, IP & Login attempts block, time-based login blocking, built-in random password generator	
VLAN	Tag-based VLAN separation	
DATA TO SERVER		
Protocol	HTTP(S), MQTT, Azure MQTT, Kinesis	
Data to server	Extract parameters from multiple sources and different protocols, and send them all to a single server; Custom LUA scripting, allowing scripts to utilize the router's Data to server feature	
API		
Teltonika Networks Web API (beta) support	Expand your device's possibilities by using a set of configurable API endpoints to retrieve or change data. For more information, please refer to this documentation: https://developers.teltonika-networks.com	
MONITORING & MANAGEME	NT	
WEB UI	HTTP/HTTPS, status, configuration, FW update, CLI, troubleshoot, multiple event log servers, firmware update availability notifications, event log, system log, kernel log	
FOTA	Firmware update from server, automatic notification	
SSH	SSH (v1, v2)	
Email	Receive email message status alerts of various services	
JSON-RPC	Management API over HTTP/HTTPS	
RMS	Teltonika Remote Management System (RMS)	
SYSTEM CHARACTERISTICS		
CPU	Mediatek, 580 MHz, MIPS 24KEc	
RAM	64 MB, DDR2	
FLASH storage	16 MB, SPI Flash	
FIRMWARE / CONFIGURATIO	N .	
WEB UI	Update FW from file, check FW on server, configuration profiles, configuration backup	
FOTA	Update FW	
RMS	Update FW/configuration for multiple devices at once	
Keep settings	Update FW without losing current configuration	
Factory settings reset	A full factory reset restores all system settings, including the IP address, PIN, and user data to the default manufacturer's configuration	



FIRMWARE CUSTOMISATION

Operating system	RutOS (OpenWrt based Linux OS)		
Supported languages	Busybox shell, Lua, C, C++		
Development tools	SDK package with build environment provided		
GPL customization	You can create your own custom, branded firmware and web page application by changing colours, logos, and other elements in our firmware to fit your or your clients' needs		
Package Manager POWER	The Package Manager is a service used to install additional software on the device		
Connector	RJ45 Socket		
Input voltage range	44.0 – 57.0 V		
PoE standards	802.3af PoE Class 1		
Power consumption PHYSICAL INTERFACES	< 2 W Max		
Ethernet	1 x RJ45 ports, 10/100 Mbps		
Status LEDs	1 x Power LED (can be turned off from web-UI)		
Antennas	2 x Internal for 2.4 GHz Wi-Fi		
Antennas specifications	2 x 2400 - 2500 MHz, 50 Ω , VSWR <2.7, gain < 4.9 dBi, omnidirectional		
Reset PHYSICAL SPECIFICATION	Reboot/User default reset/Factory reset button		
Casing material	UV stabilized plastic		
Dimensions	Ø 158 mm x 30 mm		
Weight	190 g		
Mounting options OPERATING ENVIRONMENT	AP mounting bracket (for ceiling mount)		
Operating temperature	-40 °C to 75 °C		
Operating humidity	10% to 90% non-condensing for all our devices.		
Ingress Protection Rating REGULATORY & TYPE APPRO	IP30 DVALS		
Regulatory EMC EMISSIONS & IMMUNI	CE, UKCA, EAC, ANRT, Kenya, SDPPI (POSTEL), CB, FCC, IC, RoHS, REACH, WEEE TY		
Standards	EN 55032:2015 + A11:2020 EN 55035:2017 + A11:2020 EN 61000-3-3:2013 + A1:2019 + A2:2021 EN IEC 61000-3-2:2019 + A1:2021 EN 301 489-1 V2.2.3 EN 301 489-17 V3.2.4		
ESD	EN 61000-4-2:2009		
Radiated Immunity	EN IEC 61000-4-3:2020		
EFT	EN 61000-4-4:2012		
Surge Immunity (AC Mains Power Port)	EN 61000-4-5:2014 + A1:2017		
CS	EN 61000-4-6:2014		
DIP RF	EN IEC 61000-4-11:2020		
Standards	EN 300 328 V2.2.2		
SAFETY			
Standards	CE: EN IEC 62368-1:2020 + A11:2020, EN IEC 62311:2020 RCM: AS/NZS 62368.1:2022 CB: IEC 62368-1:2018		



STANDARD PACKAGE*

- Access Point TAP100
- QSG (Quick Start Guide)
- · Wi-Fi Information sticker
- Packaging box



CLASSIFICATION CODES

HS Code: 851762 HTS: 8517.62.00

For more information on all available packaging options - please contact us directly.

AVAILABLE VERSIONS

HARDWARE VERSION	SUPPORTED FREQUENCIES	STANDARD ORDER CODE / PACKAGE CONTAINS
------------------	-----------------------	--

TAP100 *****

N/A

TAP100001000 / Standard package TAP100000000 / Standard package with EU PoE injector TAP100000200 / Standard package with UK PoE injector TAP100000300 / Standard package with US PoE injector



TAP100 SPATIAL MEASUREMENTS

MAIN MEASUREMENTS


Dimensions for TAP100:

Device housing*: Ø 158 mm x 30 mm

Box: 355 mm x 175 mm x 60 mm


TOP VIEW

The figure below depicts the measurements of TAP100 and its components as seen from the top:



BOTTOM VIEW


The figure below depicts the measurements of TAP100 and its components as seen from the bottom side:





SIDE VIEW

The figure below depicts the measurements of TAP100 and its components as seen from the front panel side: $\frac{1}{2} \left(\frac{1}{2} \right) = \frac{1}{2} \left(\frac{1}{2} \right) \left$



MOUNTING SPACE REQUIREMENTS

The figure below depicts an approximation of the device's dimensions when cables and antennas are attached:

